




# OVEN HOUSING, APPLIANCE HOUSING & LARDERS. END PANEL HARDWARE POSITIONS

Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items.  
 B = Mini-fix Bolt (Shelf) positions C = Wooden dowels

**VERY IMPORTANT NOTICE**  
 It is essential that the Appliance Manufacturers requirement for Ventilation Installation are adhered to. Failure to do so invalidates your guarantee.

**PLEASE NOTE:** The standard drilling position for an OVEN is for 900mm Oven only, (As indicated). Any other size of aperture ie: 600 or 1200mm or special Fridge Freezer will be required to be carried out by the customer or installer.












Prior to assembling unit and size of oven has been determined. Fit hinges into doors, place doors against front edge and top & bottom edges of end panel on material that will not damage face of door. The hinges will overlap a pair of hinge plate holes, were they do not the customer will be required to drill a pair of holes to accept hinge plate which screws have a maximum depth of 12mm.

Prior to assembling unit and size of appliance/s has been determined. Fit hinges into doors, place doors against front edge and top & bottom edges of end panel on material that will not damage face of door. The hinges will overlap a pair of hinge plate holes, were they do not the customer will be required to drill a pair of holes to accept hinge plate which screws have a maximum depth of 12mm.

Prior to assembling unit and door configuration has been determined. Fit hinges into doors, place doors against front edge and top & bottom edges of end panel on material that will not damage face of door. The hinges will overlap a pair of hinge plate holes, were they do not the customer will be required to drill a pair of holes to accept hinge plate which screws have a maximum depth of 12mm.


# SINGLE & DOUBLE BASE UNITS. END PANEL HARDWARE POSITIONS

Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items.  
 Do not dispose of any of the packaging until you have checked the contents and completed assembly.




# DRAWER PACK UNITS. END PANEL HARDWARE POSITIONS

Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items. Do not dispose of any of the packaging until you have checked the contents and completed assembly.







1 When using 3 drawer pack as illustrated fit drawer runners into pre-bored holes in end panels. When using 5 drawer pack a template is supplied to mark positions of holes for drawer runner positions in end panels.




# CORNER WALL UNITS. END PANEL HARDWARE POSITIONS

Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items. Do not dispose of any of the packaging until you have checked the contents and completed assembly.




## DRAWER FRONT BRACKET FIXING POSITIONS. DRAWER BOX

### 3 DRAWER PACK






### 5 DRAWER PACK

See template details below.



Please Note:  
When using 5 drawer pack a template is supplied to mark positions of holes for drawer runner positions in end panels.




# CORNER ARRANGEMENTS


Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items.

Do not dispose of any of the packaging until you have checked the contents and completed assembly.

## "L" SHAPED CORNER BASE UNIT




## CONVENTIONAL CORNER BASE UNIT



## "L" SHAPED CORNER BASE UNITS 905 X 905MM


## CONVENTIONAL CORNER BASE UNITS



## "L" SHAPED CORNER WALL UNITS 605 X 605MM

## CONVENTIONAL CORNER WALL UNIT

## IMPORTANT INSTALLATION INFORMATION



### ADJUSTABLE FEET



**IMPORTANT.** When adjusting the height of the unit make sure that the legs are not adjusted below the nominal 150mm plinth height.

### Levelling & Alignment.


Position the unit against the wall, but do not fix it in place. Check that the units are level with each other and the ends are vertical, if they are not then the foot of each leg can be screwed UP or DOWN to bring the unit level.

# BUILT UNDER OVEN HOUSING



Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items.

Do not dispose of any of the packaging until you have checked the contents and completed assembly.


## CONTENTS CHECK LIST



## BUILT UNDER OVEN HOUSING




**IMPORTANT WHEN INSTALLING AN OVEN INTO THE SITUATION SHOWN THE FOLLOWING STEPS MUST BE ADHERED TO:-**



**NOTE: THE DOORS MUST NOT BE IN CONTACT WITH THE DEFLECTORS.**


## 6 DOORS

### CLIP-ON HINGE ADJUSTMENT




## 7 PLINTH

1/2" x 6 Countersunk Screw x 2 per, plinth clip




## 6 DOORS

### CLIP-ON HINGE ADJUSTMENT



## 7 PLINTH

1/2" x 6 Countersunk Screw x 2 per, plinth clip




# SINGLE & DOUBLE WALL UNITS. END PANEL HARDWARE POSITIONS


Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items.

Do not dispose of any of the packaging until you have checked the contents and completed assembly.

## SINGLE WALL UNITS



## DOUBLE WALL UNITS




# 905 x 905 CORNER BASE UNIT. END PANEL HARDWARE POSITIONS

Please examine these drawings very carefully prior to assembly to determine the correct positions for hardware. Failure to do so could result in incorrect fitting or even damage to the items.

Do not dispose of any of the packaging until you have checked the contents and completed assembly.

## CONTENTS CHECK LIST



## 905 x 905 CORNER BASE UNIT

